# System Services: Sensors and GPS

Jianjun Chen (Jianjun.Chen@xjtlu.edu.cn)

#### Sensors

- Most Android-powered devices have built-in sensors that measure the physical environment
- Commonly used smart phone sensors
- Motion sensors
  - 3-axis Accelerometer
  - 3-axis Magnetometer
  - Gyroscope
- Environmental sensors
  - Light sensor
  - Noise

#### **Access Sensors**

- You can access sensors available on the device and acquire raw sensor data by using the Android sensor framework. Steps involved:
  - 1. Determine which sensors are available on a device.
  - 2. Determine an individual sensor's capabilities, such as its maximum range, manufacturer, power requirements, and resolution.
  - 3. Register and unregister sensor event listeners that monitor sensor changes.
  - 4. Acquire raw sensor data and define the minimum rate at which you acquire sensor data.

#### Step 1: Get List of Sensors

- First identify the sensors that are on the device
  - obtain an instance of the SensorManager class by calling the getSystemService() method.
  - passing in the SENSOR SERVICE argument.

```
private SensorManager sensorManager;
...
sensorManager = (SensorManager) getSystemService(Context.SENSOR_SERVICE);
```

We can (optionally) get a listing of every sensor:

```
List<Sensor> allSensors = sensorManager.getSensorList(Sensor.TYPE_ALL);
```

# Step 2: Check Sensor Capabilities

Test if certain type of sensor exists.

```
if (sensorManager.getDefaultSensor(Sensor.TYPE MAGNETIC_FIELD) != null){
    // Success! There's a magnetometer
} else {
    // Failure! No magnetometer.
}

• Sensor types constants:

let you determine how close the face of a device is to an object*
```

- TYPE ACCELEROMETER
- TYPE GRAVITY
- TYPE GYROSCOPE
- TYPE\_LIGHT

- TYPE\_MAGNETIC\_FIELD
- \ TYPE\_PRESSURE ← Air pressure
- TYPE PROXIMITY
- TYPE\_TEMPERATURE

<sup>\*</sup>during a telephone call, proximity sensors play a role in detecting (and skipping) accidental touchscreen taps when mobiles are held to the ear.

#### Step 3-4: Register Listener

- To monitor sensor data you need to implement two callback methods in SensorEventListener:
  - A sensor's accuracy changes.
    - onAccuracyChanged(Sensor s, int accuracy)
  - A sensor reports a new value.
    - onSensorChanged(SensorEvent e)
- Then, register the listener with sampling rate.

The rate sensor events are delivered at

#### The Sensor Object

- The sensor object allows you to get a lot of information about the related sensor.
  - getResolution()
  - getMaximumRange()
  - getMinDelay(): returns the minimum time interval (in microseconds) that a sensor can use to sense data.
    - For a streaming sensor (reports data repeatedly at a frequency), it will return a valid value.
    - For a non-streaming sensor (only report data when sensor feels the change), it will return 0.

#### Sensors Access: Summary

- Four types of interfaces
  - SensorManager: You can use this class to create an instance of the sensor service.
  - Sensor: You can use this class to create an instance of a specific sensor.
  - SensorEvent: used to create a sensor event object, which provides information about a sensor event.
  - SensorEventListener: used to create two callback methods that receive notifications (sensor events)
- Two basic tasks based on the above interfaces
  - Identifying sensors and sensor capabilities
  - Monitor sensor events

#### Sensor Example

 We will implement an app that tracks the current light level received from the ambient light sensor.



# Full example: Listener

```
public class LightSensorTest extends AppCompatActivity {
    SensorEventListener listener = new SensorEventListener() {
       @Override
       public void onSensorChanged(SensorEvent sensorEvent)_{
            float lux = sensorEvent.values[0];
            TextView tv= (TextView) findViewById(R.id.luxIndicator);
            tv.setText(String.valueOf(lux));
       @Override
        public void onAccuracyChanged(Sensor sensor, int accuracy) {
            // Do something here if sensor accuracy changes.
```

# Full example: Activity

```
private SensorManager sensorManager;
private Sensor sensor;
@Override
protected void onCreate(Bundle savedInstanceState) {
    super.onCreate(savedInstanceState);
    setContentView(R.layout.activity_light_sensor_test);
    sensorManager =
        (SensorManager) getSystemService(Context.SENSOR_SERVICE);
    sensor = sensorManager.getDefaultSensor(Sensor.TYPE LIGHT);
    sensorManager.registerListener(listener, sensor,
                                 SensorManager. SENSOR DELAY NORMAL);
@Override
protected void onPause() {
    super.onPause();
    sensorManager.unregisterListener(listener);
```

# Location Service

How to obtain current location Accuracy issues

#### Location Service

To be able to use location service, you will need:

```
LocationManager locationManager = (LocationManager)

this.getSystemService(Context.Location_SERVICE);

Activity::getSystemService(String name)
```

- Based on this LocationManager, there are two ways of obtaining location information:
  - Network-based: Using cell tower and WiFi signal.
  - Satellite-based: Using GPS.

#### Permissions

Declare permissions in the manifest file first.

#### Other Requirements

Also remember to enable the permission for your app



 Then turn on GPS on your phone (unless you decide to use network-based location service)

# The Example

- In the next example, we will build an app that allows you to:
  - Locate the current position using cell phone & WiFi signal.
  - Locate the current position using GPS-based location service.
  - Turn off location service.
- The information will be shown in the middle of the screen.



# The logic Flow

Get the LocationManager



Implement a LocationListener and
register it with the LocationManager



LocationManager will then send location information to the LocationListener. The location information is packed inside a Location object.



Unregister the LocationListener when location service is no longer needed

# Step 1: Create the Activity

- We first create the activity and its layout.
  - Here, radio group is used for single choice

public class LocationActivity extends AppCompatActivity


# Step 2: Creating Callback Class

\*This Listener is defined inside LocationActivity

```
LocationListener listener = new LocationListener() {
   public void onLocationChanged(Location location) {
       TextView tv = (TextView) findViewById(R.id.locationLabel);
       tv.setText("location=" + location.getLatitude() + "; " +
                   "time=" + location.getTime() + "; " +
                   "Accuracy=" + location.getAccuracy() + "\n");
   public void onStatusChanged(String provider,
                        int status, Bundle extras) {
       Log. . . Tester", "provider status is changed");
   public void onProviderEnabled(String provider) {
       Log.i("LocationTester", "provider is enabled");
   public void onProviderDisabled(String provider) {
       Log.i("LocationTester", "provider is closed");
};
                            Can be found out by calling
                            LocationManager.getAllProviders()
```

#### The Location Class

- It's a data class representing a geographic location.
  - getLatitude()
  - getLongitude()
  - getAltitude()
  - getSpeed()



- getAccuracy()
  - Get the estimated accuracy of this location, in meters.
- Check the API for details.



# Step 3: Configure Activity

```
@Override
protected void onCreate(Bundle savedInstanceState) {
    RadioGroup methodChoice = findViewById(R.id.LocationMethod);
    final LocationManager locationManager = (LocationManager)
        LocationActivity.this.getSystemService(Context.LOCATION SERVICE);
   methodChoice.setOnCheckedChangeListener(new
                         RadioGroup.OnCheckedChangeListener() {
        @Override
        public void onCheckedChanged(RadioGroup radioGroup, int i) {
         See the next slide
```

# Step 4: Register Callback Class

```
@Override
public void onCheckedChanged(RadioGroup radioGroup, int i) {
    if (i == radio1.getId()) {
        try
            locationManager.requestLocationUpdates(
                LocationManager.NETWORK_PROVIDER, 0, 0, listener);
        } catch (SecurityException e) { ... }
    } else if (i == radio2.getId()) {
                                          Happens when permission not granted
        try {
            locationManager.requestLocationUpdates(
                LocationManager. GPS_PROVIDER, 0, 0, listener);
        } catch (SecurityException e) { ... }←
    } else {
        locationManager.removeUpdates(listener);
        TextView tv = (TextView) findViewById(R.id.locationLabel);
        tv.setText("Location Service OFF");
```

minimum time interval between location updates, in milliseconds

minimum distance between location updates, in meters

requestLocationUpdates(LocationManager.NETWORK\_PROVIDER, 0, 0, listener)

#### The type of location service:

LocationManager.NETWORK\_PROVIDER LocationManager.GPS PROVIDER

a LocationListener whose onLocationChanged (Location) method will be called for each location update

#### Getting the Last Location

 A part from getting the location anew, you can obtain the last known location by calling:

```
Location lastLocation =
locationManager.getLastKnownLocation(LocationManager.NETWORK_PROVIDER);
```

- This method returns a Location object, from which you can get all needed <u>information</u>.
- You can use this to quickly get a (possibly inaccruate) position.

#### Obtain the Best Performance

- Flow for obtaining user location
  - Start application, get previous location stored locally
  - Start listening for updates from the location providers.
  - Maintain a "current best estimate" of location by filtering out new, but less accurate fixes.
  - Stop listening for location updates.
  - Take advantage of the last best location estimate.



#### Obtain the Best Performance

- Is the most recent location the most accurate?
  - Not necessarily
- You can validate the accuracy of a location via:
  - Check if the location retrieved is significantly newer than the previous estimate.
  - Check if the <u>accuracy</u> claimed by the location is better or worse than the previous estimate.
  - Check which provider the new location is from and determine if you trust it more.

#### Location Services: Considerations

- Location results may not be accurate
  - Multitude of location sources such as GPS, Cell-ID, and Wi-Fi have different errors
  - User movement could affect location accuracy.
- Power consumption-location measurement really drains the battery. To limit battery use:
  - Return updates less frequently
  - Restrict the set of Location Providers
  - Always check last known measurement
  - Turn off updates in Activity::onPause().

# Extended Reading

- In this lecture, both sensors and location services uses the getSystemService() function.
- There are many more types of system services.
- You should definitely check for those if your app is involved with any one of these system services.
- Check the API document for Context.getSystemService()

#### Practice

- Try to collect gravity sensor data
- Test GPS location.

\*Only after finishing the previous lab.